


Casement Care and Operation



Labeled are the vital parts of your Bristol Casement Window. Becoming familiar with them will help you better follow these instructions.

Operating and Cleaning Instructions

Easy To Open/Easy To Close

To **open** the Bristol Casement Window, first flip up the double security locks. Then simply rotate the operator **counter clockwise** until sash is opened to desired position.

To **close**, rotate operator **clockwise** until sash gently contacts casement frame. Then flip down security locks to fully seal operating sash.

DO NOT OVERTIGHTEN SASH WITH OPERATOR CRANK. THIS MAY RESULT IN DAMAGE TO CLOSURE MECHANISM.

Screens Add To Security

Each Bristol Casement Window features a non-corroding fiberglass cloth screen that slips in and out easily.

Simply disengage the screen-locks and remove.

Cleaning To Maintain Good Looks

Clean the glass in your Bristol window with any glass cleaner, or simply wipe with clean water.


The vinyl will require routine cleaning. Use a mild detergent for light soil. For heavily soiled areas a cleaner with mild abrasive is suggested. (Do Not Use On The Glass.)

Casement Routine Maintenance

Important Note: Periodically clean any debris buildup off sill track. The operating sash must be in open position to perform this cleaning. Inspect the weepholes on outside of window to see they are not clogged. If this maintenance is not done, water leakage may occur. In addition, failure to perform this maintenance could void your warranty.



SASH OPERATOR – Rotate counter clockwise to open, clockwise to close. **NEVER** operate with security lock(s) engaged. **DO NOT** overtighten; this may damage the closure mechanism.



SECURITY LOCK – Flip up to unlock, flip down to lock. Use security lock to fully seal operating sash.



SCREEN LOCKS – The locks allow easy removal and replacement of screen from inside the room.